How to Pair your SERIES-5 device with the VisionHUB

Last Modified on 10/27/2023 11:10 am PDT

<u>Summary</u>

This document shows you how to pair your SERIES-5 (white label) handheld devices to a computer with a VisionHUB.

Before you begin

- 1. Make sure you have the latest version of the MyoVision software. Download here: https://www.myovision.com/download
 - How Do I Check My Software Version?
- 2. Ensure the VisionHUB is plugged into the computer and have each device nearby and the power switch in the ON position
 - Not sure where the power switch is? See our SERIES-5 First Time Setup guide for device overview

How to pair SERIES-5 devices to your computer

1. Check that the software is properly configured

• Go to **Setup > Devices > Preferences (**or press Control + 1 on the keyboard.)



- Confirm that the "VisionHUB" option is selected
 - If you have both SERIES-5 and 3G/4G devices see our support article HERE for instructions for a Custom configuration then proceed to Step 2 "Pair your SERIES-5 devices" in this article

System HUB Setting ScanVision DynaVision FlexVision Thermography	💀 System HUB Settings
	Connected HUB Information: VisionHUB Version: 3.0 Physio Monitor Version: NC
	System HUB Information
	Solo Vision or Physio Monitor (3G/4G devices with yellow label)
	Custom (Combination of VisionHUB and Solo Vision PhysioMonitor) ScanVision Left: VisionHUB Right: VisionHUB
	Custom (Combination of VisionHUB and Solo Vision PhysioMonitor) ScanVision Left: VisionHUB Right: VisionHUB RexVision Main VisionHUB Aux VisionHUB

- If the software is not configured correctly:
 - Select the "VisionHUB" option then click "OK"

Preferences	x
System HUB Setting ScanVision DynaVision FlexVision Thermography	System HUB Settings Connected HUB Information: VisionHUB Version: 3.0 PhysioMonitor Version: NC System HUB Information VisionHUB (SERIES-5 devices with white label) SoloVision or PhysioMonitor (3G/4G devices with yellow label)
	Custom (Combination of VisionHUB and SoloVision PhysioMonitor) Custom (Combination of VisionHUB Custom (VisionHUB Custom (VisioHUB Custom (VisioHUB Custom (VisioHUB Custom (VisioHUB Custom (Vi
	2 OK Cancel Apply

2. Pair your SERIES-5 devices

- 1. When you first launch the MyoVision software with the VisionHUB plugged in, a pop-up window will prompt you to begin the pairing process. Click **Yes**, to go to the pairing window.
 - If do not see the option, close then re-open the software with the VisionHUB plugged in.
 - If you need to go back to this setting, click **Setup > Devices > Pair > Series-5** (or press "control + 5" at the same time on your keyboard).



- 2. Turn on all devices: Turn the **Power Switch** into the ON position and press the **Start Button** on each device
- 3. Press "Scan for Devices" in the "Pair Series-5 devices...." window.
 - This process can take a few minutes depending on your computer. Your devices will turn off one at a time as they pair.
 - When the pairing process is complete, a pop-up in the lower right corner will appear and each device will say "Paired" next to it.
 - The "Paired" devices will match what devices you own.
 - If not all of the expected devices paired, turn on all the devices again by clicking the start button and click "Scan for Devices." Below is an example of a DynaROM system with a Single ScanVision.



Note: The SERIES-5 handheld devices are registered to your computer's user account, not the VisionHUB. If you change user accounts or move to a different computer you will need to go through the setup and pairing process again.